



**Caution:** Bolting the kiosk station to the floor is recommended. Failure to bolt the kiosk to the floor may cause injury if the kiosk station tips over.

**Notes**

- 1 Level before drilling.
- 2 Position the rear of the template at least four inches away from a wall to allow for air circulation.
- 3 Screw or bolt into the subfloor.  
Use the following fasteners:  
**Wood:** Stainless steel lag screw: 18-8 1/4" dia 3" length, McMaster-Carr® #92351A554 or equivalent.  
**Concrete, brick or masonry:** Stainless steel bolt anchor: 18-8 1/4" dia 3" length, McMaster-Carr® #92405A198 or equivalent.
- 4 **Caution:** Do not drill into the floor with the kiosk station in place. Doing so could damage sensitive electronic components. Close and move the kiosk station before drilling.
- 5 Allow at least three feet of service access.

Title Installation Template for ID Express Station™ Kiosk				<b>STANLEY SECURITY SOLUTIONS</b>			
Series BASD	Backset	Trim style	Door thickness	Rev date 9/05	Template number BASD01	Rev —	